

# Professional Products **Professional Results**



# **ULTRA** SMOKE ODOR SEALER



BlazeMaster® and Corzan® piping systems and

products made with TempRite® Technology." "FBC™, FlowGuard Gold®, BlazeMaster® Corzan®, and TempRite® are trademarks of The Lubrizol Corporation or its affiliates.

Superior Smoke Odor Blocking

Superior Priming Capabilities

Superior Stain Blocking

## For Technical Information call 800.342.3755

These suggestions and data are based on information we believe to be reliable. They are offered in good faith, but without guarantee, as conditions and methods of use of this product are beyond our control. Neither ICP Construction, Inc., nor its agents shall be responsible for the use of this product or any procedures or apparatus mentioned. We recommend that the prospective user determine the suitability of this product, for each specific project and for the health and safety of personnel working in the area.

For additional information check Safety Data Sheet (SDS) or Product Data Sheet (PDS) available online at www.fiberlock.com

Fiberlock, the Logo and other marks on this label are trademarks of ICP Construction, Inc.



For Professional Use Only

# Universal Restoration Primer/Sealer

Permanently Encapsulates Smoke Odors On Structural, Finished and Decorative Surfaces









3095 Woodtone

126 FL 0Z 3.73 L

ULTRA RECON Smoke Odor Sealer with OdorLock Plus technol- water or oil-based paints. Not for use in HVAC systems. ogy prevents smoke odors and stains from migrating through the coating, it also contains specialized malodor neutralization **COVERAGE** technology. This multiphase technology provides one coat odor control on most surfaces and continues to block odors even with seasonal changes in temperature and humidity. ULTRA RECON Smoke Odor Sealer (Ultra SOS™) is your final step to encapsulate residual odors typically found on fire damage restoration projects.

# **SURFACE PREPARATION**

Warning! If you scrape, sand, or remove old paint from any surface, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN, PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH approved respirator to control lead exposure. Carefully clean up with a wet mop or HEPA vacuum. Before you start, find out how to protect yourself and your family by contacting the U.S. EPA/Lead Information Hotline at 1-800-424-LEAD (5323) or log on to www. epa.gov/lead.

Prior to applying Fiberlock's ULTRA RECON Smoke Odor Sealer (Ultra SOS™) it is critical that the substrate be thoroughly cleaned. Smoke odor encapsulation is a final step that needs to be part of a comprehensive smoke/odor management protocol. This protocol should include the following steps: Odor Cleaning, Odor Neutralization and Odor Encapsulation.

Fiberlock recommends cleaning with RECON Heavy Duty Cleaner or Extreme Duty Cleaner, followed by the application of ULTRA RECON Extreme Duty Odor Counteractant, After the substrate is clean, dry and sound apply ULTRA RECON Smoke wear a NIOSH approved respirator with any R, P, N or HE filter. Odor Sealer to encapsulate any residual odors that remain.

# APPLICATION TOOLS

Apply ULTRA RECON Smoke Odor Sealer with a roller or airless spray equipment.

Brush: Synthetic, nylon or polyester bristle Roller: 3/8" Nap Synthetic Fiber Spray Settings: Pressure: 2000-3000 P.S.I.

Tips: .015 to .021 tips

# PRODUCT APPLICATION

Apply ULTRA RECON Smoke Odor Sealer generously and uniformly by brush, airless spray or roller. Apply one coat of ULTRA RECON Smoke Odor Sealer and ensure that the finished

ULTRA RECON Smoke Odor Sealer is a revolutionary finish surface is properly sealed. Two-coats may be required on some grade, solvent free smoke odor sealant and stain blocker porous or heavily stained surfaces. Topcoat floor applications designed to encapsulate malodors on multiple surfaces and when foot traffic or heavy storage is expected. ULTRA RECON block tough staining. ULTRA RECON Smoke Odor Sealer with Smoke Odor Sealer is tintable up to 2 oz. of universal liquid OdorLock Plus technology is water based and does not contain colorant per gallon. Can be directly applied to wallboard, flammable solvents. Unlike typical water based coatings that sheetrock, wood, masonry and concrete. Ferrous metals may "wick" smoke odors and stains out of the substrate as they dry, require a DTM primer to prevent flash rusting. Topcoat with

Smooth Surfaces: 200-400 ft<sup>2</sup>/gal. Porous Surfaces: 100-200 ft<sup>2</sup>/gal.

# DRYING TIME @ 70°F 50% R.H

To Touch: 30 Min. Recoat: 2 Hours Topcoat: 2 Hours

# **CLEANUP**

Clean tools and drippings with warm soapy water before ULTRA RECON Smoke Odor Sealer dries. The coating and any contaminated diking material should be thoroughly air dried and collected into drums. The drums should be sealed and labeled and land-filled or incinerated according to local, regional and national regulations.

# **PRECAUTIONS**

Store in a dry place at temperatures between 40°F (4.5°C) and 90°F. (32°C). Keep closures tight and containers upright to prevent leakage. Product is non-combustible. Stir thoroughly. Do not mix with any other coatings, solvents or colors in oil. Do not apply when air or surface temperature is below 55°F, or when drying conditions are poor or when surfaces are above a 15% moisture level content. In areas with high humidity, apply when surface temperature is 60°F or higher. Use adequate ventilation during application. When applying with a sprayer, For interior use only.

# CAUTION! KEEP OUT OF REACH OF CHILDREN.

Do not take internally. Close container after each use. Keep from freezing. 24 hour Emergency "CHEM-TEL" - 1-800-255-3924

Calculated VOC: 69 g/l

# RECON ULTRA SMOKE ODOR SEALER WOODTONE - 3095 DANGER | DANGER



H351 - Suspected of causing cancer.

H351 - Susceptible de provoquer le cancer

H360 - May damage fertility or the unborn child.

Se procurer les instructions avant utilisation.|Utiliser

H360 - Peut nuire à la fertilité ou au foetus .

H412 - Harmful to aquatic life with long lasting effects.

H412 - Nocif pour les organismes aquatiques, entraîne des effets

Obtain special instructions before use.; Use personal protective equipment as required.: Avoid release to the environment.: See SDS for full list of P phrases

l'équipement de protection individuel requis. Éviter le reiet dans l'environnement.|Voir SDS pour la liste complète des phrases P

IF exposed or concerned: Get medical advice/attention.: See SDS for full list of P phrases

EN CAS d'exposition prouvée ou suspectée: Consulter un médecin. Voir SDS pour la liste complète des phrases I

Canadian Contact Info: 4050-B Sladeview Crescent Suite 200 Mississauga, ON L5L 5Y5 Canada



WARNING: Cancer and Reproductive Harm www.P65Warnings.ca.gov

3095-1 Woodtone



150 Dascomb Rd. Andover, MA 01810 (800) 342-3755 www.fiberlock.com Rev. 03.02.21