


FIBERLOCK TECHNOLOGIES




QUALITY



KNOWLEDGE



SCIENCE



GRIP-TACK

(Lead Grip/Fibertack)

Lockdown & Adhesive For Lead & Asbestos

FOR PROFESSIONAL USE ONLY
5 U.S. Gallons(18.925 Liters) Net
Max Allowable VOC Content**: 200
Actual Calculated VOC Content: <20

6408

www.fiberlock.com

ASBESTOS INSTRUCTIONS: Approved respirators must be used to prevent the inhalation of asbestos fibers that may be present in the air. Careful consideration should be given to all EPA, OSHA, and State regulations in effect at the time of application. The EPA, through the Office of Pesticides and Toxic Substances, has issued a report headed "Guidance for Controlling Friable Asbestos Containing Materials in Buildings", EPA 560/5 85-024 June 1985, containing the proper data, cautions and procedures for asbestos control. Copies are available from: TSCA Industry Asst. Office, EPA TS-799, 401 M Street SW, Washington, DC 20460, (202) 554-1404.

DEMOLITION ADHESIVE: Apply **Grip-Tack** to all surfaces prior to demolition or component disassembly. **Grip-Tack**'s adhesive membrane helps prevent surface particulates such as fibers and dust from becoming airborne by binding them together and locking them down to the surface. Airborne particulates will adhere to **Grip-Tack**'s soft tacky finish to help minimize environmental contamination during demolition and component removal projects. **Grip-Tack** should be spray applied at a rate of 150 - 200 sq.ft. per gallon.

LOCKDOWN: Sealing microscopic residual fibers after asbestos removal is mandatory on every project. Prior to post-removal air monitoring, apply one coat to all exposed surfaces.

PULLDOWN BY MISTING: Pulldown by misting the contaminated air is an effective control technique prior to post-removal air monitoring. To pull down contaminants such as dust and free-floating asbestos fibers effectively, stand in the center of the room and hold the spray gun as close to the ceiling as possible. A mist should then be sprayed parallel to surfaces in every direction or in a circle. In containment, apply one coat to the polyethylene walls and floor.

CLEANUP: Tools and drippings should be cleaned with warm soapy water before coating dries. Dispose of all waste according to current Local, State and Federal regulations.

DRYING TIME @ 70°F 50% R.H.:

To Touch: 1-2 Hours

PRECAUTIONS: Stir thoroughly. Do not add solvents, oils, or colors in oil or mix with other coatings. Do not apply when air or surface temperature is below 60°F or when drying conditions are poor. Use adequate ventilation.

CAS NO.

7732-18-5

Not avail.*

*Contents partially unknown

Chemical Ingredients

Water

Styrene-butadiene polymer

CAUTION!

KEEP OUT OF REACH OF CHILDREN.

Do not take internally. Close container after each use. Keep from freezing.

24 hour Emergency "CHEM-TEL" Phone: 1-800-255-3924

DISCLAIMER: These suggestions and data are based on information we believe to be reliable. They are offered in good faith, but without guarantee, as conditions and methods of use of this product are beyond our control. Neither Fiberlock Technologies, Inc., nor its agents shall be responsible for the use of this product or any procedures or apparatus mentioned. We recommend that the prospective user determine the suitability of **Grip-Tack** for each specific project and for the health and safety of personnel working in the area.

For additional information and/or precautions check Material Safety Data Sheet (MSDS) or Product Data Sheet (PDS) available online at www.fiberlock.com

**Maximum regulatory allowable VOC content for this category of product.

MADE IN THE USA

Manufactured by:
Fiberlock Technologies, Inc.
Andover, MA 01810
(800) 342-3755
www.fiberlock.com