


Professional Products **Professional Results**





are beyond our control. Neither ICP Construction, Inc., nor its agents shall be responsible for the use of this product or any procedures or apparatus mentioned. We recommend that the prospective user determine the suitability of this product, for each specific project and for the health and safety of personnel working in the area.

Decorative Surfaces

Superior Stain Blocking,

Recoat-Ability and Topcoating

For additional information check Safety Data Sheet (SDS) or Product Data Sheet (PDS) available online at www.fiberlock.com.

Fiberlock, the Logo and other marks on this label are trademarks of ICP Construction, Inc.



Structural Restoration Sealer Encapsulant

Permanently Encapsulates Smoke Odors On Structural Surfaces







3091 Clear

126 FL 0Z 3.73 L

malodors on multiple surfaces and block the toughest stains. requirements of NFPA 90A/90B standard. RECON Smoke Odor Sealer with OdorLock technology is water based, permeable and is not flammable. Unlike typical water **TOPCOATING** is your final step to encapsulate residual odors typically found "alligatoring" on certain substrates. on fire damage restoration projects.

SURFACE PREPARATION

Warning! If you scrape, sand, or remove old paint from any surface, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN, PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH approved respirator to control lead exposure. Carefully clean up with a wet mop or HEPA vacuum. Before you start, find out how to protect yourself and your family by contacting the U.S. EPA/Lead Information Hotline at 1-800-424-LEAD (5323) or log on to www.epa.gov/lead.

Prior to applying Fiberlock's RECON Smoke Odor Sealer (SOS™) it is critical that the substrate be thoroughly cleaned. Smoke comprehensive smoke/odor management protocol. This protocol should include the following steps: Odor Cleaning. Odor Neutralization and Odor Encapsulation.

Fiberlock recommends cleaning with RECON Heavy Duty Cleaner or Extreme Duty Cleaner, followed by the application of RECON PRECAUTIONS Extreme Duty Odor Counteractant, After the substrate is clean, any residual odors that remain.

APPLICATION TOOLS

Apply RECON Smoke Odor Sealer with a roller or airless spray equipment.

Brush: Synthetic, nylon or polyester bristle Roller: Not recommended

Spray Settings:

Pressure: 2000-3000 P.S.I. Tips: .017 to .021 tips

PRODUCT APPLICATION

Apply RECON Smoke Odor Sealer generously and uniformly by brush or airless spray. Roller application is not recommended. Apply one coat of RECON Smoke Odor Sealer and ensure that the finished surface is properly sealed. To ensure that the finished surface is properly sealed, two-coats may be required on some porous or heavily stained surfaces. Topcoat floor Calculated VOC: 60 g/l applications when foot traffic or heavy storage is expected. RECON Smoke Odor Sealer is tintable up to 2 oz. of universal liquid colorant per gallon.

HVAC Application: RECON Smoke Odor Sealer can be used to encapsulate malodors within HVAC systems as part of fire damage

3091-1 Clear

smoke odor sealant and stain blocker designed to encapsulate and unlined ductwork. RECON Smoke and Odor Sealer meets WARNING | ATTENTION

based coatings that "wick" smoke odors and stains out of the Wait at least 24 hours prior to topcoating @ 70 - 77°F, 50% R.H. substrate as they dry, RECON Smoke Odor Sealer with OdorLock Lightly sand and clean surface of Recon Smoke Odor Sealer technology prevents smoke odors and stains from migrating prior to topcoating. Do not topcoat Recon Smoke Odor Sealer through the coating while maintaining its breathability. This with anything less than a quality 100% acrylic latex coating with technology provides one coat odor control on most surfaces an eggshell sheen or higher. Avoid enamel, alkyd and oil based and continues to block odors even with seasonal changes in paint top coats. Test patch prior to application is recommended. temperature and humidity. RECON Smoke Odor Sealer (SOSTM) Failure to follow these guidelines could result in cracking or

COVERAGE

Smooth Surfaces: 200-300 ft²/gal. Porous Surfaces: 100-200 ft²/gal.

DRYING TIME @ 70°F 50% R.H

To Touch: 30 Min. Recoat: 4 Hours Topcoat: 24 Hours

CLEANUP

Clean tools and drippings with warm soapy water before RECON Smoke Odor Sealer dries. The coating and any contaminated odor encapsulation is a final step that needs to be part of a diking material should be thoroughly air dried and collected into drums. The drums should be sealed and labeled and landfilled or incinerated according to local, regional and national

Store in a dry place at temperatures between 40°F (4.5°C) and dry and sound apply RECON Smoke Odor Sealer to encapsulate 90°F. (32°C). Keep closures tight and containers upright to prevent leakage. Product is non-combustible. Stir thoroughly. Do not mix with any other coatings, solvents or colors in oil. Do not apply when air or surface temperature is below 55°F, or list of P phrases when drying conditions are poor or when surfaces are above a 15% moisture level content. In areas with high humidity, apply when surface temperature is 60°F or higher. Use adequate ventilation during application. When applying with a sprayer, wear a NIOSH approved respirator with any R, P, N or HE filter. For interior use only.

CAUTION!

KEEP OUT OF REACH OF CHILDREN.

Do not take internally. Close container after each use. Keep from freezing.

24 hour Emergency "CHEM-TEL" - 1-800-255-3924

RECON Smoke Odor Sealer is a revolutionary solvent free restoration. This product can be used in both fiberglass lined FIBERLOCK RECON SMOKE ODOR SEALER CLEAR 3091



H332 - Harmful if inhaled.

H332 - Nocif par inhalation.

H319 - Causes serious eye irritation

H319 - Provoque une sévère irritation des yeux.

H317 - May cause an allergic skin reaction.

H317 - Peut provoquer une allergie cutanée.

Use only outdoors or in a well-ventilated area.; Wear protective gloves/ protective clothing/eye protection/face protection.; Avoid breathing mist/vapours/spray.; Contaminated work clothing should not be allowed out of the workplace.; See SDS for full list of P phrases

Utiliser seulement en plein air ou dans un endroit bien ventilé.|Porter des gants de protection/des vêtements protection/un équipement de protection des veux visage. lÉviter de respirer les brouillards/vapeurs /aérosols.|Les vêtements de travail contaminés ne devraient pas sortir du lieu de travail. Voir SDS pour la liste complète des phrases P

Specific treatment (see advice on this label).: Wash contaminated clothing before reuse.; IF ON SKIN: Wash with plenty of soap and water.; IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.; Call a POISON CENTER or doctor/physician if you feel unwell.; If skin irritation or rash occurs: Get medical advice/attention.: See SDS for full

Traitement spécifique (voir les conseils sur cette étiquette).|Laver les vêtements contaminés avant réutilisation, IEN CAS DE CONTACT AVEC LA PEAU: laver abondamment à l'eau et au savon, IEN CAS DE CONTACT AVEC LES YEUX: rincer avec précaution à l'eau pendant plusieurs minutes. Enlever les lentilles de contact si la victime en porte et si elles peuvent être facilement enlevées. Continuer à rincer, l'Appeler un CENTRE ANTIPOISON ou un médecin en cas de malaise.|En cas d'irritation ou d'éruption cutanée: consulter un médecin. Voir SDS pour la liste complète des phrases P

Canadian Contact Info: 4050-B Sladeview Crescent Suite 200 Mississauga, ON L5L 5Y5 Canada

WARNING: Cancer and Reproductive Harm www.P65Warnings.ca.gov



150 Dascomb Rd. Andover, MA 01810 (800) 342-3755 www.fiberlock.com Rev. 10.17.18

For Professional Use Only