

Professional Products **Professional Results**





BlazeMaster® and Corzan® piping systems and

products made with TempRite® Technology." "FBC™, FlowGuard Gold®, BlazeMaster® Corzan®, and TempRite® are trademarks of The Lubrizol Corporation or its affiliates.

Superior Smoke Odor Blocking

Superior Priming Capabilities

Superior Stain Blocking

For Technical Information call 800.342.3755

These suggestions and data are based on information we believe to be reliable. They are offered in good faith, but without guarantee, as conditions and methods of use of this product are beyond our control. Neither ICP Construction, Inc., nor its agents shall be responsible for the use of this product or any procedures or apparatus mentioned. We recommend that the prospective user determine the suitability of this product, for each specific project and for the health and safety of personnel working in the area.

For additional information check Safety Data Sheet (SDS) or Product Data Sheet (PDS) available online at www.fiberlock.com

Fiberlock, the Logo and other marks on this label are trademarks of ICP Construction, Inc.



Universal Restoration Primer/Sealer

Permanently Encapsulates Smoke Odors On Structural, Finished and Decorative Surfaces







126 FL 0Z

grade, solvent free smoke odor sealant and stain blocker sheetrock, wood, masonry and concrete. Ferrous metals may WARNING | ATTENTION designed to encapsulate malodors on multiple surfaces and require a DTM primer to prevent flash rusting. Topcoat with block tough staining. ULTRA RECON Smoke Odor Sealer with water or oil-based paints. Not for use in HVAC systems. OdorLock Plus technology is water based and does not contain flammable solvents. Unlike typical water based coatings that **COVERAGE** "wick" smoke odors and stains out of the substrate as they dry, ULTRA RECON Smoke Odor Sealer with OdorLock Plus technology prevents smoke odors and stains from migrating through the coating, it also contains specialized malodor neutralization technology. This multiphase technology provides one coat odor control on most surfaces and continues to block odors even with seasonal changes in temperature and humidity. ULTRA RECON Smoke Odor Sealer (Ultra SOS™) is your final step to encapsulate residual odors typically found on fire damage restoration projects.

SURFACE PREPARATION

Warning! If you scrape, sand, or remove old paint from any surface, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE. ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH approved respirator to control lead exposure. Carefully clean up with a wet mop or HEPA regional and national regulations. vacuum. Before you start, find out how to protect yourself and your family by contacting the U.S. EPA/Lead Information Hotline at 1-800-424-LEAD (5323) or log on to www.epa.gov/lead.

(Ultra SOSTM) it is critical that the substrate be thoroughly cleaned. Smoke odor encapsulation is a final step that needs protocol. This protocol should include the following steps: Odor Cleaning, Odor Neutralization and Odor Encapsulation.

Fiberlock recommends cleaning with RECON Heavy Duty Cleaner or Extreme Duty Cleaner, followed by the application of ULTRA RECON Extreme Duty Odor Counteractant. After the substrate is clean, dry and sound apply ULTRA RECON Smoke Odor Sealer to encapsulate any residual odors that remain.

APPLICATION TOOLS

Apply ULTRA RECON Smoke Odor Sealer with a roller or airless spray equipment.

Brush: Synthetic, nylon or polyester bristle Roller: 3/8" Nap Synthetic Fiber

Spray Settings: Pressure: 2000-3000 P.S.I.

Tips: .015 to .021 tips

PRODUCT APPLICATION

Apply ULTRA RECON Smoke Odor Sealer generously and uniformly by brush, airless spray or roller. Apply one coat of ULTRA RECON Smoke Odor Sealer and ensure that the finished surface is properly sealed. Two-coats may be required on some porous or heavily stained surfaces. Topcoat floor applications when foot traffic or heavy storage is expected. ULTRA RECON Smoke Odor Sealer is tintable up to 2 oz. of universal liquid

3092-1 White

ULTRA RECON Smoke Odor Sealer is a revolutionary finish colorant per gallon. Can be directly applied to wallboard, FIBERLOCK ULTRA RECON SMOKE ODOR SEALER WHITE 3092

Smooth Surfaces: 200-400 ft²/gal. Porous Surfaces: 100-200 ft²/gal.

DRYING TIME @ 70°F 50% R.H

To Touch: 30 Min. Recoat: 2 Hours Topcoat: 2 Hours

Clean tools and drippings with warm soapy water before H412 - Nocif pour les organismes aquatiques, entraı̂ne des effets ULTRA RECON Smoke Odor Sealer dries. The coating and any contaminated diking material should be thoroughly air dried and collected into drums. The drums should be sealed Obtain special instructions before use.; Use personal protective

PRECAUTIONS

Store in a dry place at temperatures between 40°F (4.5°C) and Prior to applying Fiberlock's ULTRA RECON Smoke Odor Sealer 90°F. (32°C). Keep closures tight and containers upright to prevent leakage. Product is non-combustible. Stir thoroughly. Do not mix with any other coatings, solvents or colors in oil. to be part of a comprehensive smoke/odor management Do not apply when air or surface temperature is below 55°F, or when drying conditions are poor or when surfaces are above a 15% moisture level content. In areas with high humidity, apply when surface temperature is 60°F or higher. Use adequate ventilation during application. When applying with a sprayer, wear a NIOSH approved respirator with any R, P, N or HE filter. persists: Get medical advice/attention.; See SDS for full list of P phrases For interior use only.

CAUTION! KEEP OUT OF REACH OF CHILDREN.

Do not take internally. Close container after each use. Keep from freezing.

24 hour Emergency "CHEM-TEL" - 1-800-255-3924

Calculated VOC: 49 q/l



H319 - Causes serious eye irritation

H319 - Provoque une sévère irritation des yeux.

H351 - Suspected of causing cancer.

H351 - Susceptible de provoquer le cancer.

SDS pour la liste complète des phrases P

H412 - Harmful to aquatic life with long lasting effects.

and labeled and land-filled or incinerated according to local, equipment as required.; Avoid release to the environment.; Wear protective gloves/protective clothing/eye protection/face protection.; See SDS for full list of P phrases

> Se procurer les instructions avant utilisation. l'Utiliser 'équipement de protection individuel requis.|Éviter le rejet dans l'environnement.|Porter des gants de protection/des vêtements de protection/un équipement de protection des yeux/du visage.|Voir

IF exposed or concerned: Get medical advice/attention.; IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.; If eye irritation

EN CAS d'exposition prouvée ou suspectée: Consulter un médecin. LEN CAS DE CONTACT AVEC LES YEUX: rincer avec précaution à l'eau pendant plusieurs minutes. Enlever les lentilles de contact si la victime en porte et si elles peuvent être facilement enlevées. Continuer à rincer.|Si l'irritation oculaire persiste: consulter un médecin. Voir SDS pour la liste complète des phrases F

150 Dascomb Rd.

(800) 342-3755

Rev. 03.02.21

Andover, MA 01810

www.fiberlock.com

Canadian Contact Info: 4050-B Sladeview Crescent Suite 200 Mississauga, ON L5L 5Y5 Canada



WARNING: Cancer and Reproductive Harm www.P65Warnings.ca.gov



For Professional Use Only

3092 White

3.73 L