



Professional Products  
Professional Results




3093-1 REV/06/15/18

- Superior Smoke Odor Blocking
- Superior Stain Blocking
- Superior Priming Capabilities

For Technical Information call 800.342.3755  
 These suggestions and data are based on information we believe to be reliable. They are offered in good faith, but without guarantee, as conditions and methods of use of this product are beyond our control. Neither ICP Construction, Inc., nor its agents shall be responsible for the use of this product or any procedures or apparatus mentioned. We recommend that the prospective user determine the suitability of this product, for each specific project and for the health and safety of personnel working in the area.

For additional information check Safety Data Sheet (SDS) or Product Data Sheet (PDS) available online at [www.fiberlock.com](http://www.fiberlock.com).

Fiberlock, the Logo and other marks on this label are trademarks of ICP Construction, Inc.



FINISHED SURFACES  
&  
STRUCTURAL SURFACES

## Universal Restoration Primer/Sealer

Permanently Encapsulates Smoke Odors On  
Structural, Finished and Decorative Surfaces



EASILY  
ACCEPTS  
TOPCOAT



PREMIUM  
STAIN  
BLOCKER



MOISTURE  
PERMEABLE  
FINISH

For Professional Use Only

3093 Clear

126 FL OZ  
3.73 L

ULTRA RECON Smoke Odor Sealer is a revolutionary finish grade, solvent free smoke odor sealant and stain blocker designed to encapsulate malodors on multiple surfaces and block tough staining. ULTRA RECON Smoke Odor Sealer with OdorLock Plus technology is water based and does not contain flammable solvents. Unlike typical water based coatings that "wick" smoke odors and stains out of the substrate as they dry, ULTRA RECON Smoke Odor Sealer with OdorLock Plus technology prevents smoke odors and stains from migrating through the coating, it also contains specialized malodor neutralization technology. This multiphase technology provides one coat odor control on most surfaces and continues to block odors even with seasonal changes in temperature and humidity. ULTRA RECON Smoke Odor Sealer (Ultra SOS™) is your final step to encapsulate residual odors typically found on fire damage restoration projects.

### SURFACE PREPARATION

Warning! If you scrape, sand, or remove old paint from any surface, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH approved respirator to control lead exposure. Carefully clean up with a wet mop or HEPA vacuum. Before you start, find out how to protect yourself and your family by contacting the U.S. EPA/Lead Information Hotline at 1-800-424-LEAD (5323) or log on to [www.epa.gov/lead](http://www.epa.gov/lead).

Prior to applying Fiberlock's ULTRA RECON Smoke Odor Sealer (Ultra SOS™) it is critical that the substrate be thoroughly cleaned. Smoke odor encapsulation is a final step that needs to be part of a comprehensive smoke/odor management protocol. This protocol should include the following steps: Odor Cleaning, Odor Neutralization and Odor Encapsulation.

Fiberlock recommends cleaning with RECON Heavy Duty Cleaner or Extreme Duty Cleaner, followed by the application of ULTRA RECON Extreme Duty Odor Counteractant. After the substrate is clean, dry and sound apply ULTRA RECON Smoke Odor Sealer to encapsulate any residual odors that remain.

### APPLICATION TOOLS

Apply ULTRA RECON Smoke Odor Sealer with a roller or airless spray equipment.

- Brush: Synthetic, nylon or polyester bristle
- Roller: 3/8" Nap Synthetic Fiber
- Spray Settings: Pressure: 2000-3000 P.S.I.
- Tips: .015 to .021 tips

### PRODUCT APPLICATION

Apply ULTRA RECON Smoke Odor Sealer generously and uniformly by brush, airless spray or roller. Apply one coat of ULTRA RECON Smoke Odor Sealer and ensure that the finished

surface is properly sealed. Two-coats may be required on some porous or heavily stained surfaces. Topcoat floor applications when foot traffic or heavy storage is expected. ULTRA RECON Smoke Odor Sealer is tintable up to 2 oz. of universal liquid colorant per gallon. Can be directly applied to wallboard, sheetrock, wood, masonry and concrete. Ferrous metals may require a DTM primer to prevent flash rusting. Topcoat with water or oil-based paints. Not for use in HVAC systems.

### COVERAGE

- Smooth Surfaces: 200-400 ft<sup>2</sup>/gal.
- Porous Surfaces: 100-200 ft<sup>2</sup>/gal.

### DRYING TIME @ 70°F 50% R.H

- To Touch: 30 Min.
- Recoat: 2 Hours
- Topcoat: 2 Hours

### CLEANUP

Clean tools and drippings with warm soapy water before ULTRA RECON Smoke Odor Sealer dries. The coating and any contaminated diking material should be thoroughly air dried and collected into drums. The drums should be sealed and labeled and land-filled or incinerated according to local, regional and national regulations.

### PRECAUTIONS

Store in a dry place at temperatures between 40°F (4.5°C) and 90°F (32°C). Keep closures tight and containers upright to prevent leakage. Product is non-combustible. Stir thoroughly. Do not mix with any other coatings, solvents or colors in oil. Do not apply when air or surface temperature is below 55°F, or when drying conditions are poor or when surfaces are above a 15% moisture level content. In areas with high humidity, apply when surface temperature is 60°F or higher. Use adequate ventilation during application. When applying with a sprayer, wear a NIOSH approved respirator with any R, P, N or HE filter. For interior use only.

### CAUTION!

#### KEEP OUT OF REACH OF CHILDREN.

- Do not take internally.
- Close container after each use.
- Keep from freezing.
- 24 hour Emergency "CHEM-TEL" - 1-800-255-3924

Calculated VOC: 69 g/l

RECON ULTRA SMOKE ODOR SEALER CLEAR 3093  
DANGER | DANGER



H360 - May damage fertility or the unborn child.  
 H360 - Peut nuire à la fertilité ou au foetus .  
 H412 - Harmful to aquatic life with long lasting effects.  
 H412 - Nocif pour les organismes aquatiques, entraîne des effets néfastes à long terme.

Obtain special instructions before use.; Use personal protective equipment as required.; Avoid release to the environment.; See SDS for full list of P phrases

Se procurer les instructions avant utilisation. Utiliser l'équipement de protection individuel requis. Éviter le rejet dans l'environnement. Voir SDS pour la liste complète des phrases P

IF exposed or concerned: Get medical advice/attention.; See SDS for full list of P phrases

EN CAS d'exposition prouvée ou suspectée: Consulter un médecin. Voir SDS pour la liste complète des phrases P

Canadian Contact Info:  
 4050-B Sladeview Crescent Suite 200  
 Mississauga, ON L5L 5Y5 Canada

⚠ **WARNING:** Cancer and Reproductive Harm - [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

# 3093-1 Clear



150 Dascomb Rd.  
 Andover, MA 01810  
 (800) 342-3755  
[www.fiberlock.com](http://www.fiberlock.com)  
 Rev. 10.17.18